


The vertical Function Strip

Solo / Listen Modi



SOLO

This button is used to swap from Listen controlling to Solo controlling.

AFL

In the Listen mode, this button switches between pre fader and post/after fader controlling.

SOLO RESET

Press this to reset all Solo or Listen settings in the Nuendo Mixer except for the Solo Save settings.

ASCII

This is the default mode of the keyboard.

MIXER PRESET

Press this button to select one of 8 Mixer Presets.


MATRIX 1 - 48

Press this to have the keys 1 - 48 on your hands.

MATRIX 9 - 96

Press this to have the keys 49 - 96 on your hands.

Matrix Select Functions



CHAN SELECT

Press this button to select a Channel/Track. SHIFT or CNTRL allows the simultaneous selection of several tracks.

READY

Press this button to set several Tracks into the READY status.

CUT

Press this button to set several Tracks into the CUT status.

LISTEN SOLO

Press this button to set several Tracks into the LISTEN or SOLO status (this depends on the selected status on top of the strip)..